


**BATTERY SAFETY GUIDELINES:** Batteries should be replaced by an adult, remove the screw to open, fit the batteries correctly observing the "+" and "-" signs, never dispose batteries in fire, supply terminals are not to be short circuited, do not mix alkaline, standard, or rechargeable batteries, Non-rechargeable batteries are not to be recharged, do not mix old and new batteries, remove dead or old batteries from toys which are not going to be used for a long time.



## More models online

A Use your PC or tablet and go to the following link for more models:


## www.engino.com/instructions/sth61

B Download the app to discover step-by-step instructions in 3D view!

Engino kidCAD (3D Viewer) app:







**WARNING:** Do not attempt to move a motorized model by pushing it with your hands. The motor's axle can break when external force is applied. As part of our warrantee one replacement axle is included in your set. You can replace it by following the instructions found at: **www.engino.com/axle** 



## > Building Instructions

