

**vtech**<sup>®</sup>  
Baby

Parent's Guide

# Rattle-Pillar™




91-003757-000 (US) (CA)

# INTRODUCTION

Thank you for purchasing the **Rattle-Pillar™**.

Shake up playtime with this electronic rattle with a motion sensor. The cute caterpillar with a light-up heart button plays sing-along songs, playful phrases and melodies. Little ones can fine-tune their motor skills by grasping the handle and ribbon legs. Multiple textures make it extra fun to explore the **Rattle-Pillar™**!



# INCLUDED IN THIS PACKAGE

- One Rattle-Pillar™
- One parent's guide


**WARNING:** All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

**NOTE:** Please keep this parent's guide as it contains important information.

**ATTENTION :** Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

**NOTE :** Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

**Unlock the packaging locks:**




- ① Rotate the packaging lock 90 degrees counterclockwise.
- ② Pull out the packaging lock and discard.

# GETTING STARTED

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover and use a screwdriver to loosen the screws and open the battery cover.
3. Remove old batteries by pulling up on one side of each battery.
4. Install 3 new LR44 batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screws to secure.



### **WARNING:**

This product contains a button or coin cell battery. A swallowed button or coin cell battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

### **ATTENTION :**

Ce produit contient des piles boutons. Une pile bouton avalée peut causer des brûlures internes en quelques heures et peut conduire à un décès. Débarrassez-vous de vos piles usagées immédiatement après les avoir retirées du produit. Garder les piles neuves et usagées hors de la portée des enfants. Si vous pensez que votre enfant a ingéré une pile bouton ou l'a coincée dans n'importe quelle partie de son corps, consultez immédiatement votre médecin.

## BATTERY NOTICE


- Use three LR44 Alkaline button cell batteries only for this toy
- The button cell batteries used with this product should be kept away from small children who might still put things in their mouths. If the button cell batteries are swallowed, consult a doctor immediately
- Insert the button cell batteries with the correct polarity
- Do not use damaged button cell batteries
- Do not short-circuit the button cell battery terminals
- Remove exhausted button cell batteries from the product
- Remove button cell batteries during long periods of non-use
- Do not dispose of button cell batteries in fire
- Do not charge non-rechargeable button cell batteries
- Do not mix old and new batteries
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable

**DO NOT USE RECHARGEABLE BATTERIES.**

## PRODUCT FEATURES

### 1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On**  position. You will hear a playful caterpillar song, a phrase and sounds. To turn the unit **Off**, slide the **On/Off Switch** to the **Off**  position.



### 2. Automatic Shut Off

To preserve battery life, the **Rattle-Pillar™** will automatically power down after approximately 30 seconds without input. The unit can be turned on again by pressing the **Light-Up Heart Button**. The **Motion Sensor** will not turn the unit back on.


**Note:**

If the unit repeatedly powers down while playing or the light-up button fades out, we suggest changing the batteries.

## ACTIVITIES


### 1. Light-Up Heart Button

Press the **Light-Up Heart Button** to hear songs, phrases, sounds and melodies. The light will flash with the sounds.




### 2. Motion Sensor

Shake the caterpillar rattle to trigger the **Motion Sensor**. Hear sounds and phrases and watch the light flash with the sounds.



### 3. Tactile Stimulation

Encourage your baby's sense of touch with the nubby **Textured Handle** and **Ribbon Legs**.



# MELODY LIST

1. Alphabet Song
2. Simple Simon
3. A-Tisket, A-Tasket
4. Farmer in the Dell
5. Hot Cross Buns
6. London Bridge
7. Sing a Song of Sixpence
8. Ring Around the Rosie
9. Looby Loo
10. Lavender's Blue

## SING-ALONG SONG LYRICS

### Song 1

I'm a friendly little caterpillar,  
I like to crawl.  
Give me a shake, give me a wiggle,  
And hear my happy little giggle.

### Song 2

You love me, and I love you,  
My big heart is full of love.

### Song 3

Lots of colors, bright and cheerful.  
I love colors, they brighten up my day.

# CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

## **IMPORTANT NOTE:**

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

**Caution:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Supplier's Declaration of Conformity**

Trade Name: VTech®  
Model: 5278  
Product Name: Rattle-Pillar™  
Responsible Party: VTech Electronics North America, LLC  
Address: 1156 W. Shure Drive, Suite 200,  
Arlington Heights, IL 60004  
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

*CAN ICES-3 (B)/NMB-3(B)*



CLASS 1  
LED PRODUCT

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***

Read our complete warranty policy online at  
*vtechkids.com/warranty*

