

vtech[®]

Parent's Guide

Press & Pull Racer™




91-003771-000  

INTRODUCTION

Thank you for purchasing the **Press & Pull Racer™**!

This little bear loves to race! Press the bear or pull back on the race car and release it to send the car zooming, encouraging toddlers to chase after it. Songs, phrases and melodies teach colors, numbers and vocabulary with flashing lights and buttons to press. On your mark, get set, play!



INCLUDED IN THIS PACKAGE

- One **Press & Pull Racer™**
- One parent's guide

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this parent's guide as it contains important information.


ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the packaging locks:




- ① Rotate the packaging locks counterclockwise 90 degrees.
- ② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the bottom of the race car. Use a coin or screwdriver to loosen the screw and open the battery cover.
3. Remove old batteries by pulling up on one side of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance
- Use only batteries of the same or equivalent type as recommended
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries
- Do not use damaged batteries
- Insert batteries with the correct polarity
- Do not short-circuit the battery terminals
- Remove exhausted batteries from the toy
- Remove batteries during long periods of non-use
- Do not dispose of batteries in fire
- Do not charge non-rechargeable batteries
- Remove rechargeable batteries from the toy before charging (if removable)
- Rechargeable batteries are only to be charged under adult supervision




MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales
- Seules des piles du type recommandé doivent être utilisées
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés
- Ne pas utiliser des piles ou des accumulateurs endommagés
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –)
- Enlever les piles ou les accumulateurs usagés du jouet
- Retirer les piles ou les accumulateurs en cas de nonutilisation prolongée
- Ne les jeter ni au feu ni dans la nature
- Ne pas tenter de recharger des piles non rechargeables
- Enlever les accumulateurs du jouet pour les recharger
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte

PRODUCT FEATURES

1. On/Off/Volume Selector

To turn the unit **On**, slide the **On/Off/Volume Selector** to the **Low ʝ)** or **High ʝʝ)** volume position. You will hear a sound, phrase and a song. To turn the unit **Off**, slide the **On/Off Volume Selector** to the **Off ●** position.



2. Automatic Shut Off

To preserve battery life, the **Press & Pull Racer™** will automatically power down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.


Note:

If the unit repeatedly powers down while playing or the light fades out, we suggest changing the batteries.

ACTIVITIES

1. Bear Racer Button

Press the **Bear Racer Button** to propel the car forward. You will hear a song, exciting phrases, sounds and music. The light will flash with the sounds.



Note:

For your child's safety, do not press and release the race car on clothing, skin or hair. Adult supervision is recommended.

2. Pull Back and Release

Pull the car back and release it to launch the car forward and watch it zoom across the floor.

Note:

The car moves best on smooth, flat surfaces.



3. Color Buttons

Press the **Color Buttons** on the side of the car to learn about colors, racing phrases, sounds and music. The light will flash with the sounds.



4. Racing Flag

Turn the **Racing Flag** to hear it click.



MELODY LIST

1. Bear Went Over the Mountain
2. Here We Go 'Round the Mulberry Bush
3. Humpty Dumpty
4. Skip to My Lou
5. Oh! Susanna
6. Pop! Goes the Weasel
7. Looby Loo
8. Row, Row, Row Your Boat

- 
- 
9. Blow the Man Down
 10. This Old Man
 11. Big Rock Candy Mountain
 12. Camptown Races
 13. Aiken Drum
 14. Glow Worm
 15. Froggy Went a Courtin'

SING-ALONG SONG LYRICS

Song 1

Vroom, Vroom! Look at me!
Driving makes me so happy!
Pull me back, and let me go,
Racing is the life for me.

Song 2



1-2-3! I'm in first place,
Driving fast, I know I'm going to win the race.



Song 3

I'm a little speed racer.
I like to feel the wind in my fur,
Zooming down the road in my speedy car.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
 2. Keep the unit out of direct sunlight and away from any direct heat sources.
 3. Remove the batteries if the unit will not be in use for an extended period of time.
 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
- 



TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**
2. Interrupt the power supply by removing the batteries
3. Let the unit stand for a few minutes, then replace the batteries
4. Turn the unit **On**. The unit should now be ready to use again
5. If the unit still does not work, install a new set of batteries

IMPORTANT NOTE:



If the problem persists, please call our **Consumer Services Department at 1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.



Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment



generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Supplier's Declaration of Conformity



Trade Name:	VTech®
Model:	5284
Product name:	Press & Pull Racer™
Responsible Party:	VTech Electronics North America, LLC
Address:	1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004
Website:	vtechkids.com



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES-3 (B)/NMB-3(B)



**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com

Read our complete warranty policy online at
vtechkids.com/warranty



TM & © 2019 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003771-000 © 24