

**vtech**<sup>®</sup>  
Baby

Parent's Guide

# Twist & Spin Lion™




91-003759-000 US CA

# INTRODUCTION

Thank you for purchasing the **Twist & Spin Lion™**!

Little ones enjoy a new spin on sensory play with twirling action, multiple textures, bright colors and engaging sounds and music. Attaching easily to flat surfaces with a suction cup, the **Twist & Spin Lion™** makes discovery in play easy to grasp.



# INCLUDED IN THIS PACKAGE

- One **Twist & Spin Lion™**
- One parent's guide

## **WARNING:**

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

## **NOTE:**

Please keep this parent's guide as it contains important information.

## **ATTENTION :**

Pour la sécurité de votre enfant, débarrassez vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.


## **NOTE :**

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

# GETTING STARTED

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the lion's head. Use a screwdriver to loosen the screw and open the battery cover.
3. Remove old batteries by pulling up on one side of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance
- Use only batteries of the same or equivalent type as recommended
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries
- Do not use damaged batteries
- Insert batteries with the correct polarity
- Do not short-circuit the battery terminals
- Remove exhausted batteries from the toy
- Remove batteries during long periods of non-use
- Do not dispose of batteries in fire
- Do not charge non-rechargeable batteries
- Remove rechargeable batteries from the toy before charging (if removable)
- Rechargeable batteries are only to be charged under adult supervision


## MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales
- Seules des piles du type recommandé doivent être utilisées
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés
- Ne pas utiliser des piles ou des accumulateurs endommagés
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -)
- Enlever les piles ou les accumulateurs usagés du jouet
- Retirer les piles ou les accumulateurs en cas de nonutilisation prolongée
- Ne les jeter ni au feu ni dans la nature
- Enlever les accumulateurs du jouet pour les recharger
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte

## PRODUCT FEATURES

### 1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** ☐ position. You will hear a cute song, phrase and sounds.  
To turn the unit **Off**, slide the **On/Off Switch** to the **Off** ● position.



## 2. Suction Cup

Attach the suction cup firmly to a smooth, flat surface. For better suction, we recommend wetting the suction cup. For your child's safety, please check to make sure the suction cup is securely fastened before allowing baby to play.

## 3. Automatic Shut Off

To preserve battery life, the **Twist & Spin Lion™** will automatically power down after approximately 60 seconds without input. The unit can be turned on again by pressing the **Mane Button**.

### Note:

If the unit repeatedly powers down while playing or the light-up nose fades out, we suggest changing the batteries.

# ACTIVITIES


## 1. Mane Button

Press the **Mane Button** to hear playful phrases, short tunes, fun sounds, songs and melodies. When a melody or a song is playing, spin the hoop to hear fun sounds added to the melody or song. The **Light-Up Nose** will flash with the sound.



## 2. Spinning Hoop

Spin the **Hoop** to activate the sensor and hear fun sounds and short tunes. The **Light-Up Nose** will flash with the sound.



# MELODY LIST

1. Jack Be Nimble
2. Aba Daba Honeymoon
3. Looby Loo
4. Turkey in the Straw
5. Skip to My Lou
6. Toyland
7. Yankee Doodle
8. Animal Fair
9. Pat-a-Cake
10. Do You Know the Muffin Man?
11. Ring Around the Rosie
12. One Man Went to Mow a Meadow
13. Hickory, Dickory, Dock
14. I'll Give You a Paper of Pins
15. Chicken Reel

# SING-ALONG SONG LYRICS

## Song 1

Twist, twirl, spin around,  
I love to spin my hoop!  
Twisting, twirling, spinning, turning,  
Shake and move with me!

## Song 2

In the jungle,  
I love to shake,  
Playing with my favorite hoop  
Is really great!

### Song 3

I'm a cute and playful lion,  
I am the king of the jungle.  
I am strong and have a big mane,  
And I roar when I'm happy!


## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the program or activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**
2. Interrupt the power supply by removing the batteries
3. Let the unit stand for a few minutes, then replace the batteries
4. Turn the unit **On**. The unit should now be ready to play again
5. If the product still does not work, install a new set of batteries





**IMPORTANT NOTE:**

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

**Caution:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

### Supplier's Declaration of Conformity

Trade Name: VTech®  
Model: 5280  
Product name: Twist & Spin Lion™  
Responsible Party: VTech Electronics North America, LLC  
Address: 1156 W. Shure Drive, Suite 200,  
Arlington Heights, IL 60004  
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

*CAN ICES-3 (B)/NMB-3(B)*

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***

Read our complete warranty policy online at  
*vtechkids.com/warranty*

