DRIVEN
by BATTAT

AIRPORT PLAYSET

3+ YEARS

A

K

K

H J

I

C

F

F

D x2

B

H x1

C

I J

x1

E x2

I x3 J x1

F x2

A

K

G AIRPORT x1

A x1

K x2

x4

ARRIVALS DEPARTURES

x1 x1 x1

x1

x1 x1 x1 x1 x1 x2

I

E

F

F

E

I

AIRPORT

G

B

D

D

Please remove all packaging materials before giving to children.

- Rough or inappropriate usage may result in permanent damage to the toy.
- Excessive sand, dirt and/or water may cause the toy to malfunction.

WH1077

DRIVEN by BATTAT®

3+ YEARS

Before first use:

1. Pull out insulation tag as (Fig 1).

2. Press button for lights and sounds as (Fig 2).

(Fig 1)

AG13
AG13
AG13

(Fig 2)

REPLACING BATTERIES

3 x AG13 (1.5V) BATTERIES INCLUDED

· Do not mix old and new batteries.
· Do not mix alkaline, standard(carbon-zinc), or rechargeable batteries.
· Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

ATTENTION: When the module's functions lose performance, follow instructions carefully to install new batteries.

⚠ **WARNING:** This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns leading to death in as little as two hours. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.